Contents

Acknowledgments v

About the Authors xii

Preface xiii

Tip #1: Always Ask “Why?” – And Never Stop Learning 1

Tip #2: Always Note the Author of a Technical Article 3

Tip #3: Pain Is Instructive 5

Tip #4: Never Lie 7

Tip #5: Admit Your Errors 9

Tip #6: Change for the Sake of Change Is Not Always a Good Thing, but
“We’ve Always Done It That Way” Is a Poor Reason to Avoid Trying New Things 11

Tip #7: If You Have to Tell Everyone How Smart You Are, You Probably Aren’t 13

Tip #8: Never Underestimate the Power of Politics and Emotion 15

Tip #9: The O-ring Seal in an On/Off Actuator Can Be a Good
Predictor of Its Reliability 17

Tip #10: Butterfly Valves and/or Ball Valves with Positioners
Are NOT Control Valves! 19

Tip #11: The Good, the Bad, and the Ugly of Vortex Flowmeters 21

Tip #12: The Good, the Bad, and the Ugly of Magmeters 23

Tip #13: The Good, the Bad, and the Ugly of Differential Pressure Flow Devices 25

Tip #14: Capillary Seal Pitfalls 27

Tip #15: You Cannot Control What You Do Not Understand 29

Tip #16: Use Outlines and/or Flow Charts First 31

Tip #17: You Can Never Have Too Much Messaging 33

Tip #18: Cheap Instrumentation Is Exactly That 35

Tip #19: Always Run Spare Wires and Plan for Expansion 37

Tip #20: Spend the Money to Individually Fuse I/O with Indicating Fuse Blocks 39

Tip #21: Too Many Alarms Can Be Worse Than None at All 41

Tip #22: Details Matter 43

Tip #23: Anticipate Murphy; He Is Alive and Well 45

Tip #24: When Performing a DCS Retrofit, Take Time to Study the I/O Cards 47

Tip #25: Make Sure the Coffee Is Strong and the Pot Brews Quickly on Start-up 49

Tip #26: Document Your Code 51

Tip #27: Create, Thoroughly Test, THEN Replicate 53

Tip #28: “Plug and Play” Devices Often Don’t 55

Tip #29: Tricks for Control Panels. 57

Tip #30: Appearance Matters 59

Tip #31: Project Management Is Really Risk Management 61

Tip #32: General Project Management Tips 63

Tip #33: High Pay Is Great but Life Is Too Short to Stay in a Job You Dislike 65

Tip #34: Take Time to Learn Exactly How Instruments Work. 67

Tip #35: Operators Can Make or Break an Automation Project 69

Tip #36: A College Degree Does NOT Buy You Respect, Nor Is It a
Good Indication of What You Know 71

Tip #37: Get Past the References You Are Offered 73

Tip #38: Derail Scripted Demonstrations 75

Tip #39: Know the Codes 77

Tip #40: Engineers Are Generally AWFUL Communicators.
Do Not Fall into That Trap. 79

Tip #41: If Possible, Get Plant Experience Early 81

Tip #42: Money Drives Corporate Behavior 83

Tip #43: Small, Continuous Waste Streams = BIG Money 85

Tip #44: Foster Relationships with Honest Vendors 87

Tip #45: Learn to Estimate Jobs 89

Tip #46: Success Breeds Success and Mediocrity Is Never Acceptable 91

Tip #47: Grow Your Direct Reports 93

Tip #48: Treat Everyone with Respect and Do Not Accept a
Lack of Respect from Others 95

Tip #49: Working For a Boss Whom You Do Not Respect Is Difficult 97

Tip #50: Ask for Feedback 99

Tip #51: Seek Conversations with Knowledgeable People 101

Tip #52: Be a Good Listener 103

Tip #53: Find and Read Technical Articles and Books 105

Tip #54: Look for Opportunities to Improve Plant Profitability 107

Tip #55: Use the Best Technology, Even if the Price Tag Is Higher 109

Tip #56: Learn New Skills and Explore Technological Advances
as an Extracurricular Activity 111

Tip #57: Be a Team Player 113

Tip #58: Make Yourself More Marketable 115

Tip #59: Document the Benefits of Improvements 117

Tip #60: Write and Present Papers 119

Tip #61: Install Online Process Metrics 121

Tip #62: Demonstrate and Prototype Improvements via Dynamic Models 123

Tip #63: Use Field Analyzers to Measure Key Component Concentrations 125

Tip #64: Improve Setpoints 127

Tip #65: Use High Rangeability Flowmeters and Valves to Increase Plant Turndown . 129

Tip #66: Seek First Principles for a Deeper Understanding 131

Tip #67: Find the Best Measurement Location 133

Tip #68: Find the Best Valve Location 135

Tip #69: Add Control Loops to Eliminate Manual Actions and Sequences 137

Tip #70: Minimize Deadtime 139

Tip #71: Achieve Best Disturbance Rejection and Setpoint Response 141

Tip #72: Achieve Best Loop Coordination and Optimization 143

Tip #73: Use Coriolis Meters for Mass Flow and Concentration Control 145

Tip #74: Eliminate Split Range Oscillations 147

Tip #75: Use Wireless Transmitters for Diagnostics, Improvements, and Metrics 149

Tip #76: Use Checklists to Cover All the Bases 151

Tip #77: Increase the PID Gain and Reset Time for Vessel and Column Control 153

Tip #78: Decrease the PID Gain and Reset Time for Pipeline and Inline Control 155

Tip #79: Understand How Equipment and Operating Conditions
Affect Process Dynamics 157

Tip #80: Use Sliding Stem Valves for Tighter Control 159

Tip #81: Select the Best Type and Size of Actuator for Tight Control 161

Tip #82: Use and Tune Smart Positioners 163

Tip #83: Don’t Use On-Off Valves for Control Valves 165

Tip #84: Use Signal Characterization in the DCS to Linearize Valve
Installed Flow Characteristic 167

Tip #85: Use Linear Reagent Demand Control for Systems with
Difficult-to-Control pH 169

Tip #86: Test the pH Response Time to Determine the Health
of a Glass Electrode 171

Tip #87: Monitor the pH Offset to Determine the Health of a
Reference Electrode 173

Tip #88: Use Middle Signal Selection to Improve pH Measurement Reliability 175

Tip #89: Identify Deadtime and Ramp Rate 177

Tip #90: Compute and Trend a Future PV 179

Tip #91: Use Output Tracking to Improve Setpoint and Abnormal Condition Response 181

Tip #92: Make Reset Time and Feedforward Action Smarter 183

Tip #93: Use a Viewable and Adjustable Flow Ratio and a Feedforward Summer 185

Tip #94: Smooth the Transition between Batch and Continuous Operations 187

Tip #95: Use External-Reset Feedback for Cascade Control and Slow Final Control Elements 189

Tip #96: Optimize Batch End Points and Cycle Times 191

Tip #97: Use Valve Position Control to Optimize Process Efficiency and Capacity 193

Tip #98: Achieve the Required Simulation Fidelity 195

Tip #99: Use a Virtual Plant for All Dynamic Models 197

Tip #100: Use an Enhanced PID for At-Line and Off-Line Analyzers 199

Tip #101: Use Plant-Wide Feedforward for More Flexible and Efficient Production . . . 201

Appendix A: References 203

Appendix B: Vintage Books 205

Appendix C: Checklists 206

Appendix D: Dynamics 223

Appendix E: Enhanced PID 229

Appendix F: First Principle Process Gains, Deadtimes, and Time Constants 231